






## Is Your Fan Giving Low Air Delivery ?

<p><b>1</b> STEP</p>	<p>Regulator bypassing is recommended</p> 
<p><b>2</b> STEP</p>	<p>Kindly use the 5th speed or boost mode for higher air delivery.</p> 
<p><b>3</b> STEP</p>	<p>Ensure that the fan is not on Sleep Mode. Just restart the fan using either the remote or the switch to disable the Sleep Mode.</p> 
<p><b>4</b> STEP</p>	<p>Ensure that the installation is done as per the instructions provided by Atomberg Technologies.</p> 