



Is Your Fan Giving Low Air Delivery ?

<p>1 STEP</p>	<p>Regulator bypassing is recommended</p>
<p>2 STEP</p>	<p>Kindly use the 5th speed or boost mode for higher air delivery.</p>
<p>3 STEP</p>	<p>Ensure that the fan is not on Sleep Mode. Just restart the fan using either the remote or the switch to disable the Sleep Mode.</p>
<p>4 STEP</p>	<p>Ensure that the installation is done as per the instructions provided by Atomborg Technologies.</p>