







Is Your Fan's MCB Tripping?

<p>1 STEP</p>	<p>Ensure that the supply cable (Red & Black - Phase & Neutral) - are properly connected with the White OC connector. AC supply across the wires at both the points A and B should be within the range of 140Vac to 285Vac.</p>	
<p>2 STEP</p>	<p>Ensure that the fan wires aren't short circuited with the fan's hook.</p>	
<p>3 STEP</p>	<p>Ensure that MCB is not overloaded with multiple equipment connections. You may take the help of an electrician for the same.</p>	
<p>4 STEP</p>	<p>MCB must not be tripped & the supply switch/button should be "ON"</p>	
<p>5 STEP</p>	<p>Ensure that the MCB is not faulty. You may take the help of an electrician for the same.</p>	