







Is Your Fan Making Noise?

<p>1 STEP</p>	<p>Ensure that the washer bolt, plastic nut for blade & grill has been tightened properly as shown in image.</p>  <p style="text-align: center; font-size: small;">Anticlockwise-Tight Clockwise-Loose</p>
<p>2 STEP</p>	<p>In case of heavy vibration, switch on the fan by removing the blade to crosscheck if the problem is with the blade or with the motor assembly. In either case, kindly contact Atomberg's Service Team.</p>  <p style="text-align: center; font-size: small;">Without Blade With Blade</p>
<p>3 STEP</p>	<p>Install the blade according to the given pin-slot with the blade pin as shown in the image.</p> 
<p>4 STEP</p>	<p>Ensure that the knob for fixing the rod has been tightened properly.</p> 
<p>5 STEP</p>	<p>If the problem continues to persist, then re-install the fan according to the standard procedure shown in the image.</p> 