







## Does The Speed Of Your Fan Vary?

<p><b>1</b> STEP</p>	<p>Ensure that the connection is proper while plugging Power Pin into the main socket. In case of loose connection, find another compatible socket.</p> 
<p><b>2</b> STEP</p>	<p>Install the blade according to its provided pin-slot with the blade pin as shown in image.</p> 
<p><b>3</b> STEP</p>	<p>If the problem continues to persist, then re-install the fan according to the standard procedure shown in the image.</p> 
<p><b>4</b> STEP</p>	<p>Ensure that the Plastic Blade nut is tightened properly as shown in image.</p>  <p>Anticlockwise-Tight Clockwise-Loose</p>