









Is Your Fan Wobbling?

<p>1 STEP</p>	<p>Ensure that the Washer-Bolt has been tightened properly.</p> 
<p>2 STEP</p>	<p>Ensure that the knob for fixing the rod has been tightened properly.</p> 
<p>3 STEP</p>	<p>In case of wobbling issue, switch on the fan by removing the blade to crosscheck if the problem is with the blade or with the motor assembly. In either case, kindly contact Atomberg's Service Team.</p> <div style="display: flex; justify-content: space-around;">   </div> <p style="text-align: center;">Without Blade With Blade</p>
<p>4 STEP</p>	<p>If the problem continues to persist, then re-install the fan according to the standard procedure shown in the image.</p> <div style="display: flex; justify-content: space-around;">   </div>