



## Is Your Fan Giving Low Air Delivery?

<p><b>1</b> STEP</p>	<p>Regulator bypassing is recommended</p>	
<p><b>2</b> STEP</p>	<p>Kindly use the 5th speed or boost mode for higher air delivery.</p>	
<p><b>3</b> STEP</p>	<p>Ensure that the fan is not on Sleep Mode. Just restart the fan using either the remote or the switch to disable the Sleep Mode.</p>	
<p><b>4</b> STEP</p>	<p>Ensure that the installation is done as per the instructions provided by Atomberg Technologies.</p>	
<p><b>5</b> STEP</p>	<p>Ensure that the blade(s) or the motor of the fan aren't damaged or bent in any way.</p>	