






Is Your Fan Not Working?

<p>1 STEP</p>	<p>MCB must not be tripped & the supply switch/button should be "ON".</p> 
<p>2 STEP</p>	<p>Both wires (red & black- phase neutral connected to fan) must be connected properly and supply must not be broken.</p> 
<p>3 STEP</p>	<p>Switch/button of the fan must not be damaged with water or dust ensure switch is also not broken from inside.</p> 
<p>4 STEP</p>	<p>If the fan is mounted in kitchen make sure fan is not dirty or greasy as it can affect the rotation of blades causes mechanical failure. (wipe with damp cloth)</p> 