








Does The Speed Of Your Fan Vary?

<p>1 STEP</p>	<p>Regulator bypassing is recommended</p>	 <p>To bypass the regulator connect point A to point B as shown in picture.</p>
<p>2 STEP</p>	<p>Ensure that the supply cable (Red & Black - Phase & Neutral) - are properly connected with the White OC connector. AC supply across the wires at both the points A and B should be within the range of 140Vac to 285Vac.</p>	
<p>3 STEP</p>	<p>Ensure that the blades are adjusted to their corresponding motor i.e. 900mm (sweep size) blades should not be fixed to a motor of a 1400mm (sweep size) fan.</p>	
<p>4 STEP</p>	<p>We recommend the use of D-type hooks. If any other type of hook is in use, then ensure that down-rod must not have any movement while the fan is running.</p>	
<p>5 STEP</p>	<p>Ensure that the minimum adjacent distance between 2 fans should be more than 1 metre.</p>	 <p>How to space 2 fans equidistantly in a room (Room Length > 1.8m (6 feet))</p> <p>1/4 of Room 1/4 of Room 1/4 of Room 1/4 of Room</p> <p>Center of Fan Center of Room Center of Fan</p> <p>Equal Spacing Equal Spacing Equal Spacing</p> <p>Center Spacing: at 1/4 the distance of the entire room width. In this case 1/4 of Room (0.5m) and distance of 1.3m (4 feet)</p> <p>Equidistant Spacing Vertical "Landing" 2P at Ceiling</p>