






# Naveo GV4



## Does The Speed Of Your Fan Vary?

<p><b>1</b> STEP</p>	<p>For a Better Performance use step regulator as the fan will not operate at a lower range if used with a non compactible stepless (Triac based)-Regulator, also Ensure to use Eletronic Regulator only, Using Electric Regulator will affect the fan performance</p>	 <p>Electronic Regulator: Stepless Regulator (Triac), High Regulator (2 Capacitors)</p> <p>Electric Regulator: Resistor Regulator</p>
<p><b>2</b> STEP</p>	<p>Ensure that the supply cable (Red &amp; Black - Phase &amp; Neutral) - are properly connected with the White OC connector. AC supply across the wires at both the points A and B should be within the range of 140Vac to 285Vac.</p>	 <p>AC Supply at Motor Wires: 230Vac</p> <p>Customer Supply End: 230Vac</p>
<p><b>3</b> STEP</p>	<p>Ensure that the blades are adjusted to their corresponding motor i.e. 900mm (sweep size) blades should not be fixed to a motor of a 1400mm (sweep size) fan.</p>	
<p><b>4</b> STEP</p>	<p>We recommend the use of D-type hooks. If any other type of hook is in use, then ensure that down-rod must not have any movement while the fan is running.</p>	
<p><b>5</b> STEP</p>	<p>Ensure that the minimum adjacent distance between 2 fans should be more than 1 metre.</p>	 <p>How to space 2 fans equidistantly in a room Room Example: 17' x 17' (shown to scale)</p> <p>1/4 of room, 1/4 of room, 1/4 of room, 1/4 of room</p> <p>Center of Fan, Center of Room, Center of Fan</p> <p>Equal Space, Equal Space, Equal Space, Equal Space</p> <p>Center each fan at 1/4 the distance of the distance from walls. (17' x 17' room) (17' x 17' x 17' ceiling not included) x 1/4 distance</p> <p>Equidistant Spacing "Visual" Looking UP at Ceiling</p>