



## **Is Your Fan Not Working?**



MCB must not be tripped & the supply switch/button should be "ON"





Ensure that the supply cable (Red & Black - Phase & Neutral) - are properly connected with the White OC connector





Input power supply should be in the range of 140Vac to 285Vac. AC supply across the wires at both the points A and B should be within the range of 140Vac to 285Vac.





For a Better Performance use step regulator as the fan will not operate at a lower range if used with a non compactible stepless (Triac based)Regulator.









Ensure to use Eletrconic Regulator only, Using Electric Regulator will affect the fan performance









