









## Is Your Fan Giving Low Air Delivery?

<p><b>1</b> STEP</p>	<p>For a Better Performance use step regulator as the fan will not operate at a lower range if used with a non compactible stepless (Triac based)-Regulator.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Electronic Regulator</p>  </div> <div style="text-align: center;"> <p>Electric Regulator Resistive Regulators</p>  </div> </div>
<p><b>2</b> STEP</p>	<p>Ensure to use Eletrconic Regulator only, Using Electric Regulator will affect the fan performance</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Dimmer Regulator (Triac)</p>  </div> <div style="text-align: center;"> <p>Step Regulator (Capacitive)</p>  </div> </div>
<p><b>3</b> STEP</p>	<p>Ensure that the installation is done as per the instructions provided by Atomberg Technologies.</p> <div style="text-align: center;">  </div>
<p><b>4</b> STEP</p>	<p>Ensure that the blade(s) or the motor of the fan aren't damaged or bent in any way.</p> <div style="text-align: center;">  </div>