



## Does The Speed Of Your Fan Vary?

<p><b>1</b> STEP</p>	<p>Regulator bypassing is recommended.</p>	
<p><b>2</b> STEP</p>	<p>Ensure that the supply cable (Red &amp; Black - Phase &amp; Neutral) - are properly connected with the White OC connector. AC supply across the wires at both the points A and B should be within the range of 140Vac to 285Vac.</p>	
<p><b>3</b> STEP</p>	<p>Ensure that the blades are adjusted to their corresponding motor i.e. 900mm (sweep size) blades should not be fixed to a motor of a 1400mm (sweep size) fan.</p>	
<p><b>4</b> STEP</p>	<p>We recommend the use of D-type hooks. If any other type of hook is in use, then ensure that down-rod must not have any movement while the fan is running.</p>	
<p><b>5</b> STEP</p>	<p>Ensure that the minimum adjacent distance between 2 fans should be more than 1 metre.</p>	<p>How to space 2 fans equidistantly in a room Room Example: 17' x 13' (shown in square)</p>